

Congratulations on your purchase of the Andrea PC Headset ANC-700L!

The Andrea PC Headset ANC-700L features state-of-the-art, Noise Canceling microphone technology that removes background noise and echo speaker feedback for optimal voice recognition. Users receive:

- Andrea microphone technology in a high-fidelity headset that can be easily folded flat for convenient storage.
- On/Off microphone mute switch that allows for conversations that do not disrupt computer telephony and Speech-Driven PC applications during operation.
- A flexible boom microphone that can be rotated left to right for use on either ear.
- Increased speed and accuracy of PC speech-driven applications.

CONNECTING THE ANC-700L

To connect the Andrea PC Headset ANC-700L to your computer's sound card:

1. Plug the pink microphone jack (indicated by a microphone icon) into the "mic in" port.
2. Plug the green speaker jack (indicated by a sound icon) into the "speaker" port.

COMPATIBILITY

The Andrea PC Headset ANC-700L is compatible with most major sound cards, computers and laptops.

C46-5226-2 Rev C

Package includes: One (1) ANC-700L Headset,
and
One (1) ANC-700L Headset Publication.

HEADSET INSTRUCTIONS

1. Fit the adjustable headband over your head to secure the headset with the speaker resting comfortably around your ear and the temple pad about one to two inches over the other ear. Note: The microphone boom can rotate to adapt to either the right or left side of your head.
2. Adjust the microphone boom so that the microphone is approximately 3/4" in front of your mouth, making sure that you are talking into the voice side of the microphone, indicated by the white dot.
3. Attach the line cord clip about two feet from your ear (near waist level) to your clothing for easy mobility.
4. Set the switch on the rectangular box located on the line cord to "ON".

TROUBLESHOOTING

If you encounter the following problems:

No sound from headset ear piece while an audio CD plays from computer.

- A. Check all connections.
- B. Consult your sound card instruction booklet.
- C. Check output volume level adjustment in software.

Microphone does not record sound when using a voice-recording application.

- A. Check all connections.
- B. Bring the microphone closer to your mouth.
- C. Check input control for proper level in software.
- D. Check that the microphone is not muted in the PC's microphone audio panel.

TECHNICAL SERVICE

We hope that you enjoy your Andrea ANC-700L Headset. If you have additional questions, please visit our website at:
www.andreacommunications.com/support or call Andrea Communication's Technical Service team at 1-800-442-7787 (USA & Canada) for assistance.





WARRANTY INFORMATION

Please visit our website at:
www.andreacommunications.com/warranty
for all warranty information.



PC HEADSET ANC-700L





Visit www.andreacomunications.com or call 1-800-442-7787 U.S.A./Canada to order a USB-SA Adapter.